

PRO-CUT DECAL

INSTALLATION

QUICK AND EASY TO APPLY...

- 

Lay decal FACE-UP on a smooth, hard surface, then squeegee the surface to ensure good contact between the pre-mask and the vinyl beneath it.
- 

Lay decal flat FACE DOWN, then slowly remove the backing paper from the pre-mask; pulling straight back and flat, as shown (not at an angle).
- 

Apply pressure-sensitive vinyl to prepared surface, then squeegee pre-mask surface using overlapping strokes.
- 

To expose product, pull pre-masking away at an angle (as shown), using a continuous motion.
If bubbles occur in the letters, simply prick with a needle and smooth them out. Do not use a knife or razor.

NOTE:

White Pro-Cut Decals may be supplied on a colored liner for improved visibility. Clear pre-masking is also available on some items. While different liners and pre-masks may have different release properties, all material types will release successfully following the steps specified above.

Pro-Cut Decals are made with a pre-spaced, die-cut process. When applied, finished product looks like individual letters.

PREPARATION

Prepare surface by washing with a mild soap and water solution. Do not use soaps or detergents that contain creams or lotions. Once surface is free of dirt & oils, dry thoroughly with a lint free cloth.

TEMPERATURE

It is recommended that the air and application surface are both a minimum of 50° (F).

PAINTED SURFACE

If the surface is freshly painted, please allow proper curing of paint before applying the decals.

(Refer to the paint manufacturer for curing times)

PREP QUESTIONS

If you have any questions about preparing your surface for decal installation, please give us a call, or send an email to sales@conceptonetn.com

concept one
SIGNS • AWARDS • APPAREL

conceptonetn.com
615.452.2900